

Satellite receiver/DVB-T receiver
Récepteur satellite/récepteur TNT
Satelliten-Receiver/Receptor DVB-T
Satellietontvanger/DVB-T-ontvanger
Ricevitore satellitare/ricevitore DVB-T
Resctor de televisión via satélite/receptor de TDT
Resctor de satélite/Receptor DVB-T
Satellitmtottagare/DVB-T-mottagare
Αυφορητικός δέκτης/Δέκτης DVB-T

Brand	Code No.
Abat	41300
@Sky	41334
Albar	40713
Acoustic Solutions	41284
ADR	40642, 40887, 42367
ADP	41993
Amal	42348
Akara	41626
Alba	40713, 41284
Altech	40728
Altech Network Systems	41020, 41442, 41417
Althomax	41334
Amfionica	40713
Amprone	40386
Amstrad	40396, 41713, 40847, 41175, 41662, 41693, 41801, 41848, 42319
Anglo	40713
Anko	40713
Alpionic	42418
Amper	41627
Armin	41334
ASCI	41300
ASLE	41627
AscCom	40853
Atom	41129
Atena	40713
Astratec	41743
Astro	40713, 40658, 41100, 41816, 42000
ATTA	42418
Atsat	41300
ASKy	41334
AudioLine	41627
Aurora	40642, 40879
Austar	40642, 40879
Azaron	40713
Avil	41413, 41727, 41993, 42139, 42418
Aztronic	41626
Bact	41672
Bell ExpressVu	40713
Belson	42139, 42418
Best Buy	41993, 42319
BIG TV	41334
Black Diamond	41284
Blaupunkt	40713
Blue Sky	40713
Boca	40713, 42026
Boshmann	41413, 41631
Brainwave	40853, 41627
British Sky Broadcasting	40847, 41175, 41662
Bresco	40713
BskyB	40847, 41175, 41662
Buba Sat	40713
Bush	41284, 41291, 41626, 41645, 41672, 41743, 42167, 42366
Canal Digital	42466
Canal Digital	40853, 41740
Canal Satellite	40853, 42107
Canal+	40853, 42107, 42657
CanalSat	42107
CDV	41993
Century	40856
CCV	41413
Chem	40713, 41334, 41626, 42026
CityCom	40658, 41176
Classic	41672
Chromatic	40713
Clycon	41626
Clemens Kampbus	40396
Cobra	41626
Com Hem	41176, 41915
Comag	41413, 42026
Comsat	41413
Conia	42167
Connections	40396
Conlog	41672
Crown	41284
CS	41631
Cyfra+	40847, 42593
Cyfronet Polsat	40253, 40853, 42527
D-box	40723, 41114
Daeprung	40396
Dalson	40713, 41743
DAK	41993
Dantax	41626
Daxnet	41284
Ddtec	41631, 42418
Digi	42026
Digitaly	41334
Digitalvision	41645, 41743
Digihone	41284, 42034
Digibox	41300, 41631
DigiQuest	41300, 41631
DigitalBox	41100, 41631
Dimi	41993
Digitalart	41432
Dipax	41631
DirecTV	40099, 40566, 40749, 41377, 41414, 41442, 41749
Dish Network	40775
DishTV	40847, 40879
DishTV	41300
Distriatel	41704
DNET	41409
Doro	41672
Dream Multimedia	41237, 41652
DSTV	40642, 40879
Durabrand	41284, 42034
DVX	41993, 42418
Echostar	40396, 40713, 40775, 40853, 41409, 42527
Eco-Star	41413
Edision	41631
Einhell	40713
Elip	40713, 41129, 41413
Ebe	42418
Elat	40713
Energy System	41631
Engel	40713, 41801, 41993
Eurostat	40713
Expansiva	40775
F&U	42166
Fischham	42034
Ferrner	40713
Ferguson	41129, 41743
Finlux	41626
Finlux	40396
Flax Mate	40713
Fluor	41176, 41336
FMmaximal	40713
Fuba	40713, 40396, 41801
Funer	42167
Galaxis	40853, 40879
GE	40713
General Satellite	41176
Globo	41374, 41626, 42026
GOI	40775
Gold Box	41545
Gold Vision	41631
GoldMaster	41300
Goodmans	41284, 41291, 42034, 42376
Gradiente	40099, 40856, 40887
Grandin	41626
Grinco	41409
Grundig	40174, 40847, 40853, 40879, 41284, 41291, 41672, 41740, 42034, 42367, 42376
Haier	42418
Hallo	41626
Hindan	41780

Brand	Code No.
Servimat	40396
SEC	41284, 41626, 41993
Servimat	41611
Servisat	40713
Shark	41631
Sharp	42034
Shervaco	41409
Siemens	40713, 41334, 41657
Sigmatel	42139, 42418
SilverCrest	42026
Skatim	40713
SKR	40713
SKY	40099, 40847, 40856, 40887, 41176, 41499, 41662, 41693, 41848, 42019
SKY Brazil	40856, 40887, 41499
SKY Deutschland	40723, 41100, 41114, 41176, 41195, 41675, 42176
SKY India	40853, 41693, 41848
SKY Mexico	40856, 42519
SKY+	41175, 41662
Skymaster	40713, 41334, 41409, 41445, 41611
SkyStar	41989
SKySat	40713
SkyVision	41334
SL	41672, 42026
SM Electronic	40713, 41409
Smart	40396, 40713, 41413, 41631
Sojo	42166
Sony	40847, 40853, 41558, 41979
Star Digital	41176
Starland	40713
Stream	41848
Stream System	41300
Strong	40713, 40853, 40879, 41284, 41300, 41409, 41626, 41801, 42255, 42418
Sunny	41626
Sunyat	40713, 41129, 41413
Sumat	40642
Sumatech	40719, 42139
Supertona	40887
SupperPlus	41672
Supratex	41413, 41993, 42139, 42166
Supra	42418
System	41334
System	42139
Takson	41704
TATA Sky	41997
Tboston	42139, 42418
Tec	41322
Technical	41626
Technika	41284, 41672, 42034
Technostat	40396, 41100, 41195, 41197, 41322
Technosonic	41672
Technostore	41672
Technowood	41284, 41626, 42034

Video accessory
Accessoire vidéo
Videozubehör
Videoaccessoire
Accessorio video
Accesorio de vídeo
Bildtilbehør
Εξοπλισμός βίντεο

Brand	Code No.
ADB	52254
Amino	51481, 52482
AT&T	52407
Artica	52427
Belcam TV	52345
Belcam	52327
BIG TV	52425
BT Vision	51998, 52275
Cisco	52345
ClubInternet	52132
Kias	52132
KoalConnect	51481
MIO	40749
Motorola	50858, 51998, 52275, 52378

Brand	Code No.
ADB	52254
Amino	51481, 52482
AT&T	52407
Artica	52427
Belcam	52345
Belcam	52327
BIG TV	52425
BT Vision	51998, 52275
Cisco	52345
ClubInternet	52132
Kias	52132
KoalConnect	51481
MIO	40749
Motorola	50858, 51998, 52275, 52378

DVR (digital video recorder)/PVR (personal video recorder)
Enregistreur vidéo numérique/enregistreur vidéo personnel
Digitaler Videorecorder/personlicher Videorecorder
Digitale videorecorder/persoonlijke videorecorder
Videoregistratore digitale/videoregistratore personale
Videograbadora digital/videograbadora personal
Gravador de video digital/gravador de vídeo pessoal
Digital videinspelare/personlig videinspelare
Ψηφιακή συσκευή εγγραφής βίντεο/προσωπική συσκευή εγγραφής βίντεο
Dijital video kaydeditci/kişisel video kaydeditci
Digitalís videofelvévő/zsemélyi videofelvévő
Digitalnís videorekordér/osobní videorekordér
Digitalný videorekordér/osobní videorekordár
Cyfrowa nagrywarka wideo/osobista nagrywarka wideo
Цифровой видеомагнитофон/персональный видеомагнитофон
Цифровий відеозаписувач/персональний відеозаписувач
Digitalnís videosnimáč/osobní videosnimáč

Brand	Code No.
Go Video	20739
Go Video	20614, 20616
Hughes Network Systems	20739
Humax	20739
Panasonic	20618, 20636, 20739
Philips	20618, 20739

Brand	Code No.
TTE System	40396, 41409, 41611, 41801
Tevison	40713, 41611
Tekla	40396
Telstar	41100, 41195, 41197, 41334, 41626, 41672
Television	41631
Televex	41300, 41334
Televisa	40887
Teleson	40713, 40847, 40853, 41672, 41993
Thomson	40713, 40847, 40853, 41175, 41291, 41461, 41626, 41997, 42107, 42176
Tiny	41672
TNT SAT	41027, 42564
TNT	40713, 41611
Togfield	41545, 41783, 41986
Toshiba	40749, 41284, 41749
Transparent Video System	41848
Triax	40396, 40713, 40853, 41291, 41413, 41611, 41626, 41631, 42026
Turnast	40713
TVB	41989
TVP	41993
Twinnex	40713, 41611
ULC	40079, 41356, 42463
Umden	40722
Universum	40173
US Digital	41535
USDTV	41626
America Action	60278
American High	60015
Amrad	60072, 60278
Anam	60037, 60162, 60226, 60240, 60278
Anam National	60162, 60226, 61562
Amtech	60072
Amtronic	60081
ASA	60037, 60081
Asus	60240
Anka	60037, 60038, 60072, 60081
Audio Dynamics	60040
Audioblab	60081
Audiocision	60278
Audiowox	60037, 60278
AVP	60352
Awa	60043, 60048, 60072, 60104, 60315
AXI	60037
Basic Line	60072, 60104, 60278
Beamat	60240
Beko	60033, 60081, 60593, 60642
Bell & Howell	60104
Beta	60642
Black Diamond	60642
Black Panther	60278
Black	60081, 60162, 60226
Blue Sky	60037, 60072, 60278, 60348, 60352, 60642, 61137
Bondtech	60072
Bosch	60642
Brinkmann	60348
Bronkonic	60348
Brow	60081, 60078, 60315, 60348, 60352, 60642
Calix	60037
Canon	60015
Carat	60081
Carrefour	60045
Carver	60081
Carby	60078
CCP	60072, 60278
Centrum	60593
Changebox	60048, 60081
Cineline	60072
Cineral	60348
CineVision	61137
Cinova	60037, 60278
Claronic	60072
Colt	60072
Combitech	60352
Condor	60278
Crage	60037, 60072, 60240
Crowley	60081
Crown	60037, 60072, 60278
Curtis Mathes	60035, 60066, 60162, 60240, 60278
Cyrex	60040
Daevo	60045, 60104, 60278, 60352, 60642, 61137
Danaos	60072, 60278
Dantax	60348, 60352
Dartex	60278
Deca	60067, 60081, 60352
De Graaf	60042, 60048, 60081, 60104
Decca	60067, 60081, 60352
Denon	60072
Denso	60042
Denon	60042, 60048, 60081, 60104, 60240, 60278, 60315
Deon	60037
Oceanic	60078, 60081, 60104, 60320
Okano	60348
Diplymp	60035, 60226
Digison	60642
Diplex	60642
Dial	60081, 60278, 60348
Dion	60348, 60352
Durabrand	60038, 60593, 60642
Eibe	60038, 60278
Elo	60072
Electrohome	60037, 60043
Electrohome	60037
Elin	60240
Elex	60072, 60642
Elex	60072, 60278
Emetec	60032
Emerson	60035, 60037, 60038, 60040, 60042, 60240, 60278, 60348, 60593
ESA	61137
Philips	60035, 60048, 60104, 60226, 60593
Phoenix	60278
Orion	60081
Osaka	60037
Otto Versand	60072
Pace	60352
Pacific	60348, 60642
Palladium	60037, 60278, 60348
Panasonic	60072, 60642
Panasonic	60035, 60162, 60226, 60638, 60837, 61062, 61562
Panasonic	60042
Panney	60035, 60037, 60038, 60040, 60042, 60240
Pentax	60042
Peris	60035, 60038, 60072, 60226
Peris	60035, 60048, 60226, 60593
Phoenix	60278
Phonix	60072
Pilot	60043, 60067, 60081, 60162
Pink Audio	60072
Portland	60278
Profronic	60081, 60240
Flint	60278, 60320, 60642
Proscan	60660
Proso	60278
Prosonic	60278
Protex	60072
Protech	60072, 60081
Provision	60278
Pro	60081
GEC	60060
General	60045
General Technic	60348
Genexa	60037, 60048, 60072, 60081
Go Video	60240, 60452, 61137
GoldHand	60037
GoldStar	60037, 60038, 60226, 61137
Goodmans	60037, 60067, 60081, 60240, 60278, 60348, 60352, 60642
GPX	60037
Gradiente	61137
Gratz	60104, 60240
Granada	60037, 60042, 60048, 60081, 60104, 60226, 60240
Grandin	60037, 60072, 60278
Grandin	60072, 60081, 60226